



# Simulink® for System and Algorithm Modeling

## Modeling Logical Systems






# Outline

- Defining the system and identifying its components
- Modeling the system with equations
- Building a block diagram for the model
- Defining and configuring signal viewers
- Setting the configuration parameters
- Introducing zero crossing
- Variable-step versus fixed-step solvers
- Modifying the signal viewer parameters
- Simulating the model and analyzing the results
- Defining the maximum step size
- Modeling the system with Embedded MATLAB
- Simulating and comparing results

# Defining the System and Identifying Its Components

- The electronic throttle PI controller outputs a signal.



- The variables in this system are the controller output ( $u$ ), duty, and direction:
  - The controller output,  $u$ , is the system input.
  - Duty and direction are the system outputs.
  - There are no states or parameters to this system. Both duty and direction are computed directly from the input signal.

# Modeling the System with Equations

- The system input is  $u$ . **Duty** and **Direction** are the system outputs.
- The duty is constrained to fall within the range of  $0 \leq \text{duty} \leq 1$ .

$$\text{Duty} = \begin{cases} |u| & \text{if } 0 \leq |u| \leq 1 \\ 1 & \text{if } |u| > 1 \end{cases}$$

$$\text{Direction} = \begin{cases} 1 & \text{if } u \geq 0 \\ -1 & \text{if } u < 0 \end{cases}$$

# Building a Block Diagram for the Model

- Start by adding a From File block to the model. Label the block output  $u$ . This is the system input signal.
- Next, connect a Sign block to the  $u$  signal.
- Use Switch blocks to implement the two **if** statements.
- Limit the **duty** signal with a Saturation block.  
( $0 \leq \text{duty cycle} \leq 1$ )
- Connect the system outputs to Outport blocks.


$$Duty = \begin{cases} |u| & \text{if } 0 \leq |u| \leq 1 \\ 1 & \text{if } |u| > 1 \end{cases}$$

$$Direction = \begin{cases} 1 & \text{if } u \geq 0 \\ -1 & \text{if } u < 0 \end{cases}$$

>> `etc_logic`

# Defining the Block Diagram I/O



- Set the **File Name** parameter for the From File block to `pi_output.mat`.
- To define the Outport block parameters, open the **Model Explorer** from the **View** menu of the model. Select the model you are working from **Model Hierarchy** in the **Model Explorer**.
- Check that **Time** and **Output** are selected.
- Modify the **Save to workspace** variable names for **Time** and **Output**.



# Adding Signal Viewers



The Signal & Scope Manager lets you create and view signals without using blocks:

- Select **Tools > Signal and Scope Manager**.
- Go to **Types > Viewers > Simulink > Scope**.
- Create a Simulink Scope viewer with two axes.
- Connect the Duty signal to the first axis and the direction signal to the second axis of the viewer.



# Modifying the Viewer Parameters

- Open the Viewer by double-clicking the  icon.



Print

Scope parameters

Zoom in

Zoom in x direction

Zoom in y direction

Autoscale


Save axes settings

Restore axes settings



# Controlling the Vertical Limits of the Viewer

- Open the axis properties dialog box by selecting **Axes properties** from the context menu after right-clicking in the axis.
- Set the vertical axis limits using the **Y-min** and **Y-max** fields.



'Scope' properties: duty

Y-min: -0.01 Y-max: 0.1

Title ('%<SignalLabel>' replaced by signal name):  
%<SignalLabel>


OK Cancel Apply

'Scope' properties: direction

Y-min: -1.5 Y-max: 1.5

Title ('%<SignalLabel>' replaced by signal name):  
%<SignalLabel>

OK Cancel Apply



# Introducing Zero Crossings

- Simulink works by establishing a dialog between the system and the solver.
- Simulink can carry messages from the system to the solver.
- One important message is “There has been a zero crossing!”
- Zero crossings:
  - A signal changes sign.
  - A block changes mode.
- Missing zero crossings can result in inaccurate representation:
  - Bouncing of a ball

# Zero Crossing Types

- Blocks with zero-crossing support:

Abs

Backlash

MinMax

Dead Zone

Sign

Integrator

Switch

Relational Operator

Relay

Saturation


Step

Hit Crossing

- Each block defines its own zero crossings.


- Zero crossings can be

- Rising — Signal rises to or through zero or signal leaves zero and becomes positive.




Trigger

- Falling — Signal falls to or through zero or signal leaves zero and becomes negative.




Trigger

- Either




Trigger



# Selecting a Solver for Zero-Crossing Detection

Select **Simulation** → **Configuration Parameters** → **Solver**

- For solver options:
  - Select a **Variable-Step, discrete** solver.
  - Set **Zero crossing** control to **Use local settings**



# Working with Zero Crossings

- Discrete blocks cause discontinuities.
  - Event detection is not required.
  - Events happen only at update times!
- Zero-crossing detection can be turned off for an entire system or individual blocks:
  - Configuration Parameters dialog box
  - Individual block parameters dialog box
- It is possible to create models whose responses go through zero several times in an infinitesimal period, and cause repeated detection of zero crossings at the same step, practically bringing simulation to a stop.


>> **chatter**

# Simulating the Model and Analyzing the Response

- To simulate the model from the command line, type  

```
>> [t,x,y] = sim('etc_logic')
```
- To visualize the system output,  

```
>> plot(t,y(:,1),t,y(:,2))  
>> legend('Duty','Direction')
```
- Turn **Zero crossing control** off for the model and simulate again.
  - Is there a difference in the results?



## Defining the Max Step Size


- If the **Max step size** is `auto` and there are no zero crossings or continuous states in the model, Simulink computes a step size of

$$h = \frac{t_{stop} - t_{start}}{50}$$

- This is why you have 51 points in the simulation when zero-crossing detection is turned off.
- You can force a smaller step size by specifying it.

```
>> set_param('etc_logic', 'ZeroCrossControl', 'Disable')
>> [t_off, x_off, y_off] = sim('etc_logic');
>> length(t_off)
```

# Modeling Logic with Embedded MATLAB Function Blocks




```
Embedded MATLAB Editor - Block: etc_logic_eml/Embedded MATLAB Function
File Edit Text Debug Tools Window Help
[Icons]
1 function [duty, direction] = u2dd(u)
2
3
4 if u >= 0
5     duty = u;
6     direction = 1;
7 else
8     duty = -u;
9     direction = -1;
10 end
11 if duty < 0
12     duty = 0;
13 elseif duty > 1
14     duty = 1;
end
```

```
>> etc_logic_eml
```




# Simulating the Models and Comparing the Results

- Simulate the both versions of the logical systems with zero-crossing detection turned on.
- Compare the system outputs using MATLAB.
- Are there differences?
- Why?
- How can you make them behave the same?



```
>> edit etc_logic_analysis
>> etc_logic_analysis
```



# Summary

- Defining the system and identifying its components
- Modeling the system with equations
- Building a block diagram for the model
- Defining and configuring signal viewers
- Setting the configuration parameters
- Introducing zero crossing
- Variable-step versus fixed-step solvers
- Modifying the signal viewer parameters
- Simulating the model and analyzing the results
- Defining the maximum step size
- Modeling the system with Embedded MATLAB
- Simulating and comparing results